


Instruction Manual

KE-8 Keyboard Mimic



Museum Technology Source Inc.

323 Andover Street Wilmington MA 01887
800-729-6873 978-657-3898 fax 978-657-7132
www.museumtech.com

April 2002
Firmware 03-15-02

Introduction

The KE-8 Keyboard Mimic provides an easy and straightforward method of interfacing contact closures, such as pushbuttons, to a personal computer. Connection to the computer is via the standard PC keyboard connector. Inputs for eight pushbuttons are provided. When a contact is made, the keystrokes programmed into the KE-8 are transmitted to the PC. As far as the PC is concerned, this data is indistinguishable from that provided by the standard keyboard. If illuminated pushbuttons are used, the KE-8 will flash the lamp briefly. This is useful in that it provides visual feedback. The KE-8 is programmed by connecting it between the keyboard and the PC. The red Program button is pressed, the desired keystrokes are typed, and the desired button is pressed. Upon pressing one of the eight buttons, the keystrokes are stored in that button's location. Once the buttons are programmed, the keyboard may be disconnected; the PC will boot and operate with just the KE-8.

Installation

With the PC powered down, unplug the keyboard from the computer, and plug it into the Keyboard connector on the KE-8. Using the supplied cable, connect the PC connector on the KE-8 to the keyboard connector on the PC. At this point it is not necessary to connect the external pushbuttons or power supply to the KE-8. The KE-8 derives operating power from the host computer.

Turn on the computer. After it has booted, open a word processing program such as Notepad, which may be found in the Accessories folder under the PC's Start menu. The choice of program is not critical; any program that will display what is being typed is fine.


With Notepad open, type a few characters to confirm that the keyboard is working. If not, check that the keyboard and computer cables have not been inadvertently interchanged. In order to program Button 1, press the red Program button on the KE-8, and type the characters that you wish to have associated with Button 1. Now press Button 1; the green LED next to Button 1 will blink, and the red Program light will extinguish. As a test, now press Button 1. The screen should display the characters just typed. Repeat this process for the remaining buttons. Each button will store a minimum of 5 characters, in some cases as many as 10. If the maximum number of characters is exceeded, the red Program light will turn off.

External Connections

The rear panel of the KE-8 has eight RJ-11 modular telephone style connectors which are used to connect the external pushbuttons (or other contact closure, such as a motion sensor or proximity switch). If the buttons have been supplied by Museum Technology, they are already wired. If locally supplied buttons are to be used, follow the wiring diagram. The center pair of contacts are for the switch, while the outer pair provide 12 volts for button illumination.

The KE-8 derives its operating power from the PC. The external 12 volt DC power supply is required to provide button illumination or to supply power to sensors. If non-illuminated buttons are used, the external power supply is not required.

FRONT PANEL



REAR PANEL

